

Model: TK-ROD1000 Suspension Rod Installation Instructions



Decide location of track ensuring enough clearance from lighting object. Use at least three rods per track.

Hang Rods From Ceiling:

1. Loosen screws **A** and unwind the Chrome ceiling mounts from rods.
2. Fasten the mounts to ceiling with the appropriate wood, metal thread or toggle fastening system.
3. The threaded rods and plastic sleeving can be cut shorter.
4. Fit the rods into the ceiling mounts and ensure that all screws **A** are then tightened.

Assemble the Track:

1. Wind the threaded hole **T** of a track mount onto each rod, check with strong line that they are all level and in line. Tighten nuts **N**.
2. Slide track into position, then tighten all screws **B**.
3. Follow model TK Tracklight Systems Installation Instructions for completion of installation.
4. Securely cable tie the supply cord to suspension rod at supply end.

