















and associated equipment. Refer to AS/NZS 3000 before installation of recessed luminaries

fire damage to property if not installed and maintained correctly. Recessed Luminaires and their associated equipment may pose risk of Caution:

where ambient temperatures exceed 35 degrees.

- Please note that this downlight must not be installed
- Tan be mounted into timber ceiling. building insulation blankets or segments abutted to sides.
- Class CA135 This will run safely with non-flammable installation:

back the spring clips and slide into ceiling.

- 7. Insert the SDR48 into the ceiling by holding
- Ensure mains power supply cable is clamped securely. Live (L), Meutral (N) and Earth (E).
 - 2. Connect power supply to connector block,
 - 4. Cut a 230mmL x 130mmW hole in the ceiling.
 - 3. Cavity size must not be less than $0.2 \mathrm{M}^3$. MIC=30mm, SCB=75mm, HCB=100mm.
 - 2. When choosing downlight position ensure that
 - 1. Minimum cavity depth required 230mmH.


Isolate the electrical power supply. Install using a registered electrician.

Basic installation instructions:

Model:

SRD48-TLT-WH superl

Rectangular LED Downlight



<u>kuhedus</u>

- Titltable to 60 degrees
- Flange 250mm x 150mm
- 4,000K



48W LED similar to 70W Metal Halide SRD48-TLT-WH



Colour: WHITE

High Power LED ENGINEERED FOR FIRE SAFETY AND YOUR PEACE OF MIND

Manufactured in China