## Use and maintenance instructions

### **CERCHIO LANTERN HEAD - F1068**

superlux we engineer light

Outdoor luminaire suitable for installation on poles Ø60mm

TECHNICAL DETAILS: please refer to the product label



```
Insulation Class II
```



Protection degree against dust ingress, solid particles, moisture



1068182, 1068184 This luminaire holds a lighting source in "D" energy efficiency class.



1068282, 1068284 This luminaire holds a lighting source in "E" energy efficiency class.



Caution, risk of electrical shock. The lighting source of this luminaire must be replaced by the Manufacturer only.



This product must not be disposed as a normal household waste

### WARNINGS:

- THE SAFETY OF THIS PRODUCT IS GUARANTEED ONLY WITH THE RESPECT OF THE EXISTING RULES FOR THE ELECTRICAL SYSTEMS, AND WITH THE APPROPRIATE USE OF THESE INSTALLATION INSTRUCTIONS, THEREFORE IT IS NECESSARY TO KEEP THEM
- THE IMPROPER USE OF THIS PRODUCT IS FORBIDDEN; ANY TAMPERING WITH THE PRODUCT OR MODIFICATION OF THE PRODUCT THAT IS NOT AUTHORIZED BY MARECO LUCE CAN CAUSE DAMAGE TO PEOPLE, ANIMALS OR THINGS, AND WILL VOID ANY WARRANTY OR LIABILITY.
- SWITCH OFF THE ELECTRICITY BEFORE CONDUCTING ANY KIND OF MAINTENANCE.
- THE PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH BEST PRACTICE.
- DAMAGED COMPONENTS MUST BE REPLACED WITH MARECOLUCE ORIGINAL SPARE PARTS.
- DO NOT PLACE ANY OBJECT ON THE TOP OF THE LUMINAIRE AND DO NOT COVER THE DIFFUSER IN ANY WAY.

# GENERAL MAINTENANCE RECOMMENDATIONS:

• CLEAN THE LUMINAIRE PERIODICALLY TO REMOVE POSSIBLE DIRT DEPOSITS THAT MAY DAMAGE IT OR ALTER THE PHOTOMETRICS PERFORMANCE.

 DO NOT USE HARSH DETERGENTS, ABRASIVE CLOTHES, HIGH- PRESSURE WASHERS, WATER AT A TEMPERATURE HIGHER THAN 60°C TO CLEAN THE LUMINAIRE.

 CHECK THE INTEGRITY OF THE FITTING COMPONENTS: REPLACE THEM IN CASE OF DAMAGE BY USING ONLY ORIGINAL MARECO LUCE PARTS.


 VERIFY THAT THE GRUB SCREWS THAT FIX THE LUMINAIRE TO ITS SUPPORT (POLE / BRACKET/...) ARE DULY TIGHTENED.

#### **INSTALLATION INSTRUCTIONS:**

1. Connect the luminaire to the mains by using a watertight connection, and paying attention to respect the polarities and the insulation class.

CAUTION: use only a flexible supply cable in double sheath type HAR, or suitable for outdoor use, of section not less than 1 sgmm.

2. Insert the luminaire on the pole and tighten the dowels (2) tightly.



Size in mm

Adapte r D 60 d min

min 65

52 h